

Battery Mountings



Use the screws to fit the 20mm hexagonal pillars into the 2 holes provided. One, directly between the motors and the other close to the rear edge. Tighten the screws firmly.

