

## **Right Side of Sleigh**



This is the matching side to yesterday's piece. Fit in the same way as the left side: remove the two screws from the right motor, then apply the side piece, making sure that the large hole passes around the protrusion on the motor around the axle. Then do up the screws again as before, not forgetting the 3mm spacer. Fit the wheel back on carefully.

