

Motor Mounting



Today we start building.

You have received 2 hexagonal spacers, 30mm long. One is Female-Female and the other is Male-Female. Using a pair of pliers as shown below, screw the two parts together enclosing the ring in the centre of the **Chassis**. Screw them together as tight as possible.

NOTE: Take care not to scratch the circuit board when tightening the spacers together.

