

Motor Mounting the Second



This is the second set of motor mounts.

You have received 2 hexagonal spacers, 30mm long. One is Female-Female and the other is Male-Female. Using a pair of pliers, screw the two parts together enclosing the remaining ring in the centre of the **Chassis**. Screw them together as tight as possible.

NOTE: Take care not to scratch the circuit board when tightening the spacers together.

The assembly should look like the photo below when you have finished

