

### Motor Fitting Screws (Left)



#### **WARNING: Fiddly bit of assembly!**

Fit the screw through the flange in the motor, then fit through the 3mm nylon spacer and finally into the motor mounting that you fitted on Day 4. Leave this very loose.

Do the same with the second screw and nylon spacer. Because you left the first screw very loose, you will be able to rotate the motor away from the mounting so you can fit the 3mm spacer onto the end of the screw, before fitting the screw into the mounting. Plug the cable into the connector next to the motor

