


Using the Buzzer Gizmo with Playground for Crumble

Requirements:

- Playground for Crumble with Crumble attached and batteries installed
- Buzzer Gizmo
- 1 x Connection cable

Connections:

1. Switch Playground OFF
2. Plug connection cable into Gizmo and Pin A on Playground
3. Switch Playground ON



Simple Software Demo:

This software will sound the buzzer briefly once per second.

