


## Using the Flame Gizmo with Playground for Crumble

### Requirements:

- Playground for Crumble with Crumble attached and batteries installed
- 2 x Flame Gizmos
- 2 x Connection cable

### Connections:

1. Switch Playground OFF
2. Plug connection cable from Pin D on Playground to Input on 1<sup>st</sup> Gizmo
3. Plug another cable from Output of 1<sup>st</sup> Gizmo into Input on 2<sup>nd</sup> Gizmo
4. Switch Playground ON



### Simple Software Demo:

This software will flash the two Gizmos separately and in different colours.

